

# Barentz.

Our Smoothing Hair Serum is D5 free and can provide excellent smoothing benefits. Featuring Mirasil D-DML VT is a volatile silicone blend that provides shine and an anti-static benefit. Mirasil DM2 a light weight volatile offset to D5. Puresil ORG03 a unique silicone blend shown to improve frizz and flyaways while adding shine to hair.

## Smoothing Hair Serum



# Smoothing Hair Serum

Supplier	Description	INCI	w/w%	Phase	Product Information
Elkem	Mirasil D-DML VT	Dimethicone or Dimethiconol	76	1	a blend of high MW dimethiconol gum in a volatile low viscosity silicone fluid. It is typically used as an emollient or conditioner in skin and hair care products.
Elkem	Mirasil DM 2	Dimethicone	15	1	A light Dimethicone alternative to D5
Elkem	Puresil ORG03	C13-15 Alkane (and) Dimethicone/Vinyl Dimethicone Crosspolymer	5	1	A high natural content silicone blend that maintains skin moisturization, adds shine and glow to hair and skin, and provides softness and curl definition to hair
Oxiteno	Oxismooth CO	Isoamyl Cocoate	1.7	1	All natural silicone alternative & emollient that provides excellent moisturization & sensorial benefits
Cirebelle	CireNat Marula	Sclerocarya Birrea (Marula) Seed Oil	2	1	High in antioxidants, easily absorbed and contains high levels of oleic acid and linoleic fatty acid
Flavor and Fragrance Specialties	Kadum Plum	Fragrance	0.3	1	Sweet Aroma
			100		

Formula # PC-54

## Method

1. Add Mirasil D-DML VT to the main vessel and begin agitation.
2. Carefully add Mirasil DM 2 and mix until homogenous..
3. Slowly add the remaining ingredients individually and mix until homogenous.

**Appearance:** Clear with black spheres

**Odor:** Kaduka Plum

**Viscosity:** : 2,000-3,000 cps

**pH:** : N/A

The information given here is believed to be reliable. Barentz makes no guarantee as to the accuracy, reliability and completeness of this information. All suggestions are made without guarantee since the conditions of use are beyond our control. In no event shall Barentz be liable for damages of any nature arising out of the use of this information. Barentz disclaims the use of any material referenced above, either alone or with other materials. It is the responsibility of the user to observe legal regulations and patents.