



Hand Sanitizer with Ticacel HV Powder and MarQuat™ 30M

Trade	INCI	Function	% as added
SD Alcohol 40-B	Ethanol	Disinfectant	27
TicaCel HV Powder	Methylcellulose	Rheology Modifier	0.65
MarQuat™ 30M	Polyquaternium-10	Rheology Modifier	0.65
Water	Water	Carrier	26.7
SD Alcohol 40-B	Ethanol	Disinfectant	43
Glystar A31	Sorbitol and Glycerin	Humectant	2
			100

Procedure

1. Add Ethanol and slowly disperse TicaCel HV Powder and MarQuat™ 30M into the main tank. Mix with moderate agitation.
2. Slowly add Water. Mix with high agitation until uniform and no lumps or fish eyes are visible.
3. Add Ethanol slowly and mix until homogeneous.
4. Add Glystar A31 and mix until homogeneous. The solution should be translucent.

DISCLAIMER: The information contained herein is based on current knowledge and experience and from tests performed in a controlled environment. No responsibility is accepted that the information is sufficient, complete or correct in all cases. Users should consider the data only as a supplement to other information. Product specifications should be verified by users prior to usage. Users should make independent determination of suitability and completeness of information from all sources to assure proper use of this product and the safety of user's customers. Users should be aware that results may vary depending on use of and/or mixture of this product with other products. The determination of suitability of the above product for any particular use is solely the responsibility of the user. 5-21-2020 NP